

Air Compressor Safety Notice

DUNN & WATSON | 12V DC AIR COMPRESSOR

Read and follow this safety notice and the compressor operating instructions before use.

Caution

To reduce the risk of electrical shock, injury or product damage:

1. Do not disassemble, modify or attempt to repair the air compressor yourself.
2. Refer servicing or repairs to a qualified technician.
3. Do not use the compressor where it may fall or be pulled into water or other liquids.
4. Do not attempt to retrieve the compressor if it has fallen into water or liquid while connected to power.
5. Use this compressor with a 12V DC vehicle power system only.
6. Do not leave the compressor unattended while in use.

Warning

1. Keep out of reach of children. Do not allow children to operate the compressor.
2. The compressor may become very hot during use and can remain hot after operation. Allow it to cool before handling.
3. Do not use near flames, explosive materials, aerosols or flammable vapours.
4. Do not operate where oxygen is being administered.
5. Use only for pumping atmospheric air. Do not use with other gases.
6. Do not operate while tired, impaired or distracted.
7. Only use attachments and accessories suitable for this compressor.
8. Never point an air nozzle, hose or sprayer at yourself or another person.
9. Wear safety glasses or goggles when operating the compressor.
10. Use only in a well-ventilated area.

Keep These Instructions

Please read and follow all operating instructions before using your Dunn & Watson air compressor. Correct use will help improve safety, performance and product life.

Important Operating Notes

1. Always operate the compressor within its rated pressure range. Maximum pressure: 150 PSI.
2. This compressor is fitted with automatic thermal overload protection. If the compressor overheats, the protection system may shut the unit down. Turn the compressor off and allow it to cool for approximately 15 minutes before restarting.
3. A short start-up delay may occur when the compressor is switched on while pressurised. This is normal and does not indicate a fault.
4. It is recommended to keep the vehicle engine running while using the compressor to help reduce battery drain and maintain compressor performance. Only operate the vehicle in a well-ventilated area.
5. Always check hose connections, clamps and fittings before use.
6. Store the compressor in a clean, dry location when not in use.